

---

Manual for Use of

# FalCon eXtra

© 2005 FalCon GmbH



The information contained in this manual is subject to change without prior notification.  
© Copyright 2005 FalCon GmbH, Falkner Consulting für Messtechnologie. All Rights Reserved.  
*MS-DOS* and *Windows* are registered trademarks of the Microsoft Corporation.

# Content

<b>INTRODUCTION.....</b>	<b>1</b>
<b>Which modules can be included in FalCon eXtra .....</b>	<b>1</b>
FalCon Quick View.....	1
FalCon FrameMerge .....	2
FalCon ImagerControl.....	2
FalCon Animator3AX.....	3
FalCon MovXact.....	4
FalCon Mov3D.....	5
FalCon Mov6D.....	5
FalCon MovBag .....	5
FalCon CamFolder .....	5
<b>Which programs supplement FalCon eXtra .....</b>	<b>6</b>
FalCon Quick View DB .....	6
FalCon Customer View.....	7
<b>Installation .....</b>	<b>8</b>
Running the setup program .....	8
Installation of the Hardlock Driver.....	10
<b>System requirements.....</b>	<b>12</b>
<b>STANDARD MENUS .....</b>	<b>13</b>
<b>The File menu .....</b>	<b>14</b>
New .....	15
New Analysis .....	16
Open.....	17
Print Setup.....	20
License .....	20
Program Settings .....	20
Exit.....	22
<b>The View menu .....</b>	<b>22</b>
Tool bar.....	22
Status bar.....	22
<b>The Language menu.....</b>	<b>23</b>
Deutsch (German) .....	23
English .....	23
<b>The Help menu (?).....</b>	<b>23</b>
Help Topics .....	23
Program Warnings.....	23
About .....	24
<b>PICTURE.....</b>	<b>27</b>

<b>The File menu .....</b>	<b>28</b>
JPEG Settings .....	28
Page Preview .....	31
<b>The Edit menu .....</b>	<b>32</b>
Color Depth .....	35
Dither .....	35
Median Cut .....	36
Black/White .....	37
Gray Values .....	37
16 Colors .....	37
256 Colors .....	37
True Color .....	37
White Balance .....	38
Daylight .....	39
Tungsten Lighting .....	39
Neon Lighting .....	39
No White Balance .....	39
Selection by Cursor .....	39
Input White Balance .....	40
Set Color Gain .....	40
Input Black Level .....	41
Color Matrix .....	42
Ekta .....	43
Neutral .....	43
DCS .....	44
Brightness/Contrast .....	46
Gamma of Monitor .....	49
Sharpening .....	52
Sharpen by Filter .....	52
Sharpen by Frequency .....	59
Sharpen by Intensity .....	59
Remove Sensor Edges .....	60
Equalize Different Sensor Sensitivities .....	61
Optimize .....	61
Copy .....	62
Picture Size .....	62
Flip and Rotate .....	63
JPEG Settings .....	63
Reset Settings .....	63
<b>AVI FILE CREATION .....</b>	<b>65</b>
<b>The File Menu .....</b>	<b>67</b>
Page View .....	68
<b>The AVI-Creation Menu .....</b>	<b>69</b>
<b>AVI Creation: Document Window and Functions .....</b>	<b>70</b>
Enter .....	71
Add .....	72
Remove .....	73
AVI Create .....	73
Preview .....	74
Recording Rate .....	74
Selection .....	75
Insert .....	75
Insert - Logo .....	76
Insert - Text .....	77

Insert - Time .....	77
Insert – Picture Number .....	77
<b>MULTI AVI CREATION.....</b>	<b>79</b>
<b>PICTURE TRANSFORMATION .....</b>	<b>81</b>
<b>FRAMEMERGE .....</b>	<b>83</b>
<b>COMPRESSION .....</b>	<b>85</b>
<b>The File Menu.....</b>	<b>86</b>
Page Preview .....	87
<b>The AVI Compression Menu.....</b>	<b>87</b>
<b>AVI Compression: Document Window and Functions.....</b>	<b>88</b>
Search.....	89
Add AVI.....	89
Delete .....	90
Compress AVIs .....	90
Compressor options.....	90
<b>AVI VIEWER .....</b>	<b>93</b>
<b>The Movie Menu .....</b>	<b>94</b>
Display Time/ Picture Number.....	97
Time Display Format .....	97
Go to Time/Image .....	98
Playback Speed .....	98
Set Start Time.....	98
Image Size.....	99
Master Panel.....	100
Film Stripe Overview .....	101
Info.....	102
<b>MEASUREMENT DATA VIEWER.....</b>	<b>105</b>
<b>The File Menu.....</b>	<b>106</b>
Open .....	106
Page Preview .....	107
<b>Graph: Document Window .....</b>	<b>108</b>
Changing the Diagram Output Area.....	108
Changing the Document Window Size .....	108
Access to Graphs via Mouse .....	108
Synchronizing Graphs and AVIs with Master Panel.....	109
Synchronizing Graphs and AVIs with the Mouse .....	110
<b>The Graph Menu.....</b>	<b>111</b>
Load Additional Graph.....	113
Delete Graph .....	113
Select Active Graph .....	113
Header Data.....	114
Scaling.....	115
Layout of Axes .....	117

Font and Color for Labeling of Axis .....	118
Define Colors .....	119
Show Graph Values.....	120
Cursor at Graph .....	122
Zoom with Mouse .....	122
Moving the Time Window .....	123
Legends .....	123
Copy .....	124
<b>PROGRAM SETTINGS .....</b>	<b>125</b>
<b>Page Preview .....</b>	<b>128</b>
<b>ETHERNET CONTROL.....</b>	<b>131</b>
Entering the test name .....	131
Ethernet Control .....	132
Ethernet Control - Test .....	133
Ethernet Control – Films – Overview – Set-up .....	134
Ethernet Control – Films – Overview – Control .....	135
Ethernet Control – Films – Overview – Download .....	136
Ethernet Control – Films – Camera Data .....	138
Ethernet Control – Films – Picture Data .....	139
Ethernet Control – Change... ..	140
Ethernet Control – Deleting Defaults .....	140
<b>IMAGERCONTROL.....</b>	<b>143</b>
<b>CUSTOMER VIEW .....</b>	<b>145</b>
<b>MOVXACT – IMAGE ANALYSIS.....</b>	<b>147</b>
<b>Introduction .....</b>	<b>147</b>
1. Measuring Object Positions.....	148
2. Calibrating Measurement Value Output.....	149
Work Steps in a MovXact Analysis .....	152
General Information .....	153
MovXact Terms.....	154
MovXact Cooperating Partners .....	157
<b>Marker Types + Algorithms .....</b>	<b>158</b>
<b>The File Menu.....</b>	<b>162</b>
New Analysis .....	162
Open .....	164
Save As.....	165
<b>The Analysis Document Window .....</b>	<b>166</b>
<b>The Analysis Image and Zoom.....</b>	<b>170</b>
<b>The Analyze Menu.....</b>	<b>175</b>
<b>The MovXact Settings Dialog .....</b>	<b>177</b>
<b>The Interactive Measuring Dialog .....</b>	<b>184</b>
<b>The Set Up Markers Dialog.....</b>	<b>195</b>

1. Set up without Marker Defaults .....	195
2. Set up with a Marker Default List .....	201
3. Set up with a Marker Default File .....	201
Marker-Specific Tips.....	201
<b>The Track Markers Dialog.....</b>	<b>204</b>
Special Mode Group.....	207
<b>The Dropout Help Dialog .....</b>	<b>209</b>
<b>The Calibration Dialog .....</b>	<b>214</b>
<b>The Calibration/Time Dialog .....</b>	<b>219</b>
<b>The Calibration/Camera Dialog.....</b>	<b>220</b>
<b>The Calibration/Scale Planes Dialog .....</b>	<b>225</b>
<b>The Calibration/Depth Dialog.....</b>	<b>228</b>
<b>The Calibration/2D Coordinate System Dialog .....</b>	<b>232</b>
<b>The Diagrams/T-Diagrams Dialog.....</b>	<b>236</b>
<b>The Diagrams/X-Diagrams Dialog.....</b>	<b>242</b>
<b>The Diagrams/Save Curves Dialog .....</b>	<b>244</b>
<b>The Edit menu .....</b>	<b>250</b>
<b>The Edit/Markers Dialog.....</b>	<b>251</b>
Edit/Markers – Basic Settings .....	251
Edit/Markers – Template.....	252
Edit/Markers – Methods .....	253
Edit/Markers – Trajectory .....	258
<b>The Edit/Contours(t).....</b>	<b>261</b>
<b>The Edit/Stencils Dialog.....</b>	<b>261</b>
<b>The Edit/Export Dialog.....</b>	<b>262</b>
<b>The Edit/Import Dialog .....</b>	<b>267</b>
<b>The View Menu .....</b>	<b>272</b>
<b>The Marker Defaults (*.mrd) Document .....</b>	<b>273</b>
<b>The Picture List Document (*.pli).....</b>	<b>274</b>
<b>How Do I Measure Differences to Position? .....</b>	<b>276</b>
<b>How Do I Measure an Angle? .....</b>	<b>278</b>
<b>How do I Measure the Impact Angle in a Top View? .....</b>	<b>281</b>
<b>How to adjust a perpendicular view ? .....</b>	<b>285</b>
<b>MOVBAG – AIRBAG ANALYSIS.....</b>	<b>287</b>

<b>Introduction .....</b>	<b>288</b>
<b>The Interactive Measuring + MovBag Menu.....</b>	<b>290</b>
<b>The Contour-Options Dialog: Methods.....</b>	<b>292</b>
<b>The Contour-Options Dialog: Display .....</b>	<b>298</b>
<b>Coordinate System + Scale .....</b>	<b>301</b>
<b>Diagram Output: T Diagrams .....</b>	<b>303</b>
<b>Diagram Output: X Diagrams.....</b>	<b>304</b>
<b>CAMFOLDER – CAMERA CALIBRATION .....</b>	<b>307</b>
<b>Terms.....</b>	<b>308</b>
<b>The File Menu.....</b>	<b>309</b>
<b>Working with the Menu.....</b>	<b>310</b>
<b>The Camera Folder Document Window .....</b>	<b>311</b>
<b>Insert Items into the Camera Folder .....</b>	<b>312</b>
<b>Calibration Measurement.....</b>	<b>316</b>
Tab Control Points.....	316
Tab Image Points.....	318
Tab Parameters .....	322
Tab Evaluation .....	327
<b>Layout for ASCII-Control Point Diagrams .....</b>	<b>334</b>
<b>Coded Markers.....</b>	<b>335</b>
<b>Tips When Making Recordings of the Test Panel .....</b>	<b>336</b>
<b>MOVXACT3D .....</b>	<b>341</b>
<b>Overview .....</b>	<b>342</b>
Tracking data: control and unknown points .....	342
Calibration measurements .....	342
? Position measurements .....	342
? 3D measurements .....	342
<b>Terms.....</b>	<b>343</b>
<b>Requirements for 3D Measurements .....</b>	<b>343</b>
<b>Work Steps.....</b>	<b>344</b>
<b>Calibration Measurement.....</b>	<b>345</b>
<b>Layout of ASCII Point Tables.....</b>	<b>346</b>
<b>Coded Markers.....</b>	<b>348</b>

<b>ANIMATOR3AX .....</b>	<b>349</b>
<b>FALCON QUICK VIEW DB – CLIENT / VISAVI .....</b>	<b>351</b>
Quick View DB / VisAvi Toolbar .....	353
File Menu .....	353
Database Server Selection .....	354
Database Default Setting .....	355
Work Directory .....	360
<b>Test Navigation.....</b>	<b>362</b>
Toolbar .....	363
Tree Window.....	364
Properties Window.....	365
Filtering .....	373
Filters for Text Fields.....	375
Filters for Date .....	376
Filters for Numbers .....	377
Filters for Yes/No.....	378
Sorting Options .....	379
<b>ISO Export.....</b>	<b>380</b>
<b>Administering the Archive .....</b>	<b>382</b>
Authorized PCs .....	383
Edit User.....	384
Editing User Groups.....	385
Picture File Format.....	386
View .....	386
Camera Number .....	387
CD .....	387
Access to Films .....	388
Access to Measurement Channels.....	389
<b>Tests.....</b>	<b>390</b>
Test New/Copy/Select.....	390
Edit/Run Test .....	392
Edit Test – Test – General.....	393
Edit Test – Test – Access Limitations .....	394
Edit Test – Film – Overview – Setup .....	398
Edit Test – Film – Overview – Control .....	399
Edit Test – Film – Overview – Ethernet.....	400
Edit Test – Film – Overview – External.....	401
Edit Test – Film – Camera .....	402
Edit test – Film – Picture Settings .....	404
Edit Test – Measurement Value .....	405
Enable Test.....	407
Revoking the Enable for a Test .....	409
<b>FALCON DB-SERVER .....</b>	<b>415</b>
Introduction .....	415
Tasks of the Program.....	416

<b>The Main Window</b> .....	<b>417</b>
Connections .....	417
Database Used .....	418
Open Connections and Tables .....	418
<b>File Menu</b> .....	<b>419</b>
If the Server is Working .....	419
If the Server is Not Working .....	419
Open Database .....	420
Verify CD .....	420
Exit .....	421
<b>Settings</b> .....	<b>423</b>
<b>Times for Writing CDs</b> .....	<b>423</b>
<b>Backup Destination</b> .....	<b>424</b>
<b>System Administrator</b> .....	<b>425</b>
<b>Permitted Domains</b> .....	<b>426</b>
<b>Save for How Long</b> .....	<b>426</b>
<b>Jukebox Administration</b> .....	<b>427</b>
<b>Importing Graphs</b> .....	<b>431</b>
<b>Database Backup</b> .....	<b>432</b>
<b>Start CD Write</b> .....	<b>432</b>
<b>Connected Users</b> .....	<b>432</b>
<b>MODIFY SAMPLING RATE</b> .....	<b>433</b>
<b>What Is Modify-Sampling-Rate?</b> .....	<b>433</b>
<b>What Does Modify-Sampling-Rate Do?</b> .....	<b>433</b>
<b>Background</b> .....	<b>433</b>
<b>Interactive Operation</b> .....	<b>434</b>
<b>Batch Mode</b> .....	<b>436</b>
<b>IMC-TELNET</b> .....	<b>437</b>
<b>GLOSSAR</b> .....	<b>439</b>
<b>INDEX</b> .....	<b>441</b>

# Glossar

DIAdem

ISO-Crash

PIAS



# Index

## 1

16 colors 32

## 2

256 colors 32

## 3

3 or more 125, 178

## A

Access 129, 137–38, 137–38, 166, 171

Access 136, 138, 161, 166, 171

Access authorization 129

**Active** 161

Add 61, 64, 66–67, 66–67, 79

Add AVI 81

Add pictures 65

after 139, 177

AND 151

Aperture 122, 126, 176, 181

AVI 63, 127, 129, 133, 178, 182

AVI Compression 127

AVI file 126

AVI Quality 127

AVIs 124–25, 124–25

## B

BAC 12, 15

Backward 87

BAP 12

based on 129, 136, 156–57, 156–57

before 125, 129, 140, 142, 154, 158, 178

Black balance 36, 117

Black/White 32

Brightness balance 117

Brightness/contrast 41, 117

## C

Cache 139

camera 2

Camera 122, 126, 146, 165, 176, 180

Changes 181

Clear 124, 177

Close 9, 357

Color depth 29

Color gain 117

Color Gain 35

Color matrix 37

Color optimization 56

Color settings 117

Compression 61, 79, 80, 83

Compression options 117

Compression type 182

Consult 143

Control computer 129

Convolution 47

**Copy** 102, 168, 173, 186

Cost center 162

**Create** 61, 68, 168, 172

Create AVI 68

Create AVI 65

Ctrl 122, 176

**Cursor at Graph** 101, 112

CVT 15

## D

Data navigation 140

Database 353, 355–56, 361, 365, 369

Dats 95

Daylight 34

Daylight balance 117

DCS 39

DCS color matrix 39

DCS200 matrix 117

**Default enable** 186

Default settings 115, 118

**Define Colors** 101

Delete 70, 82, 139, 161, 171, 183, 187

**Delete graph** 101–3

Deletion strategy 139

Department 162

Description 121, 122, 126, 134, 143, 162, 164, 171, 176, 181, 183

Diadem 95

Digital filter 47, 54

**Directory** 137–38, 137–38, 172, 180

Directory default settings 117

Dither 29

Document type AVI viewer 85

Domain 161, 356, 364

Double click 142

Double-click 129

Download interval 125, 127, 178, 181

Download interval 127

Drag and drop 129

**Drive space** 139

## E

Editing the tool bar 27, 102  
EKTA 38  
EKTA color matrix 38  
EKTA matrix 115  
enable 162  
Enable 168, 185  
**English dialogs** 19  
ETH 12  
Ethernet 124–25, 124, 126, 129, 161, 177, 178, 181  
Ethernet address 136, 161  
exactly 122, 153  
Exactly 160, 176  
excluding 154  
exclusively 140  
Exit 9, 18, 369  
Exposure 126  
Exposure time 122, 176, 181

## F

FalconData 139  
Faster 77  
FastEthernet 161  
**File** 9  
Film engineer 121, 171  
Film name 181  
Filtering 151  
Flip 58  
Focal length 122, 126, 176, 181  
Font X axis 117  
Font Y axis 117  
for 151  
Forward 87  
fps 178, 181  
Frames/s 125, 126  
Free.dat 369  
Frequency 54

## G

Gamma 44  
Gamma values 117  
**German dialogs** 19  
Graph area 101  
Graphics card 8  
Graphs 109  
Graphs.usf 369  
Gray values 32  
greater than 155  
greater than 155

## H

Halogen balance 117  
Hard drive 365  
**Header Data** 101, 104  
**Help** 9, 11, 19

## I

Identify 122, 176  
Image number 87  
Images menu EDIT 219  
including 154  
**Incorrect** 365–66  
Individual steps 21, 61  
Installation 5  
Intensity 54  
Interpolation 55  
interrupts 153  
IPCONFIG 161  
ISO-Crash 95

## K

Key frames 127, 182

## L

**Language** 9  
LANGUAGE 19  
**Layout of Axes** 101  
Lens 127, 182  
less than 155  
**License** 10  
Line deletion 117  
**Load additional graph** 101  
Loading 115  
**Location** 136, 161  
Long name 181  
**Long names** 133–34, 133–34

## M

Main group 163  
Master panel 92  
Master panel settings 117  
MAV 12  
maximum 356  
Measurement engineer 121, 171  
Median cut 31  
Memory 8  
Menu entries 9  
Menu item Cancel program and restart 358  
**Mouse Zoom** 102  
MOVIE 85  
MRD 11  
MS Access 356  
Multiple selection 61, 67, 82, 317

## N

**Navigator** 129, 133, 139–40, 139–40, 143, 160, 171,  
181, 183  
Neon 34  
Neon balancing 117  
Network 123, 177  
Network problems 132  
Neu 10

Neutral 39  
Neutral color matrix 39  
Neutral matrix 116  
**New** 10  
No 156, 161  
No balance 34  
not 122–25, 129, 132, 134, 138–39, 138–39, 142,  
151, 154, 156–57, 156–57, 165, 169, 171, 175–  
76, 182, 187  
not equal 155  
Numeric entry on X axis 117  
Numeric entry on Y axis 117

## O

off 140  
On 168  
Open 9, 12, 18  
OR 151

## P

**Page Preview** 10  
Password 140  
PCMCIA 179  
**Performing tests** 129  
PIAS 95  
Picture alignment 117  
Picture data 124–25, 124, 129, 178, 179–80, 179–80,  
183  
Picture file format 127, 164, 182  
Picture number 93  
picture size 85  
Picture view 122  
Pictures – FILE area 22, 62  
Pictures - menu EDIT 26  
Pictures document type 119  
PLI 12  
Popup menu 27  
Ports 356  
Preview 61, 64, 69  
Print 9  
**Print setup** 10, 16  
Printout 123, 126, 176, 181  
**Program Settings** 10  
Projector functions 85  
**PSE** 12

## Q

Quality 133, 161, 182  
queries 172  
queries 172

## R

Recording rate 64  
Recording Rate 64, 69  
registration 140  
Registry database 115

Remove 68  
Remove sensor limit lines 55  
replay 85  
**Resolution** 127, 182  
Right mouse button 27  
Rotate 58  
Run test 169

## S

Save 9  
**Save As** 10  
Scaling 105, 112  
Select 139, 168, 171, 186  
**Select Active Graph** 101, 103  
Selection 64, 70  
Selection by cursor 34  
**Send To** 10  
Sensor limit 55  
Sensor sensitivity 56  
Server 129, 136, 137–38, 137–38, 161, 165, 171, 178,  
182  
SETUP 5  
Sharpening factor 117  
Sharpening type 117  
Shift 122, 176  
**short names** 133  
**Short names** 133  
simultaneous 178  
Simultaneous 125  
Sorting order 157  
SQL 151  
SRV1 132  
Start 123, 161, 177  
Start database server 357  
Start time 126  
Start time 126  
Start Time 87, 90, 181  
Status bar 18, 315  
Stop 87, 124, 177  
Storage location 166  
Storing 115  
Sub-group 163  
Synchronous 92  
System administrator 132  
**System number** 136, 161  
System requirements 8

## T

Terminate connection 370  
Test database 129, 140  
**Test date** 121, 171  
Test engineer 121, 171  
Text Fields 153  
**Time Window to Left** 102  
Tool bar 11, 12, 18, 315  
Toolbar 140–41, 140–41, 160  
Topmost 87  
TRA 12

Tree window 137, 141, 156–57, 156–57  
Triggers 124, 177  
True color 32  
Tungsten 34  
Type of color matrix 115  
Type of white balance 117

## U

User balance 117  
User defined color matrix 40  
**User group** 162, 171  
User matrix 117

## V

Vehicle type 121, 171  
Video for Windows 61, 77  
**View** 9, 18, 57, 122, 125, 126, 164, 176, 178, 181,  
180, 181  
View of picture 126–27, 126–27

## W

White balance 33  
White balance input 35  
Work directory 131  
Work Directory 137–38, 137–38  
**Work File Values** 101

## Y

Yes 156, 161